

5 lb Propane Tank Bracket

BKT-2285

Thank you for your purchase of a Power Tank 5 lb Propane Tank Bracket.

Assembly: Remove the yellow thread protector and black thumb nut in order to separate the t-bolt from the strap. Be careful not to lose the silver cap if it is loose. Thread this end through the rectangular holes on your bracket from the front of the bracket to the back and back to the front. Reinstall the t-bolt.

Use: Your propane tank bracket uses a quick-release strap. To operate, insert your 5 lb propane tank into the bracket and loosen the thumb nut until the "T" can be secured by the latch. Then, tighten the thumb nut until hand tight. This prevents the thumb nut from backing out and ensures the latch can not come loose. There should be no movement of your propane tank. To remove your propane tank, unscrew the thumb nut until the latch can be released.

Power Tank will not be held responsible for lost or damaged propane tanks or propane tank brackets due to improper tightening of the thumb nut.

Properly Assembled T-Bolt

