



Using your Power Tank

- 1. Connect the hose to the Regulator Coupler***
- 2. Turn Tank Valve C-Clockwise to open***
- 3. Turn Regulator Knob C-Clockwise until desired output pressure is reached (see bottom gauge)***
- 4. Ready to use.***

Shutting down your Power Tank

- 1. Turn Tank Valve Clockwise to close***
- 2. Turn Regulator Knob Clockwise or use air tool to purge the pressure in the hose***
- 3. Now you can release the hose and safely***