

Power Tank Instructions

Power Tank Power Plate—BKT-2250

Thank you for purchasing a Power Tank Power Plate Mount! This install requires only basic hand tools. Please read all instructions first, before beginning the install. This bracket fits 5 lb, 10 lb, and 15 lb Power Tanks.

What's included:

- (H1) 6x 1/4-20 x .750" hex cap screw
- (H2) 6x 1/4-20 flanged nut
- (H3) 6x Hole Adapter
- (P1) 1x Power Plate

You will need:

- 7/16" wrench
- 3/16" allen wrench
- Medium strength Loctite or threadlocker (optional)
- Power Tank Super Bracket (sold separately)
- Bedside Storage Panel (sold separately)

Assembly Instructions:

- A. Mockup where you will mount your Power Tank Super Bracket to the bed side storage panel. Note which holes line up with the Power Plate. The Power Plate has pre-drilled holes for 5 lb, 10 lb, and 15 lb Super Brackets and can be used parallel or perpendicular to the Super Bracket. The Power Plate can be rotated 90 degrees to best suit your mounting application.
- B. Note: Power Tanks can be transported in any orientation but must be, at minimum, 30 degrees from horizontal in order to use them. You can get around this by installing a [Snorkel Tube \(P/N: VLV-6010\)](#) in your Power Tank, allowing both horizontal and vertical use.
- C. Install hardware as shown. The screw (H1) goes through the red spacer (H3), the Super Bracket, the bedside storage panel, the Power Plate (P1), and finally, the flange nut (H2). Make sure the red spacers are centered in the holes on your Super Bracket.

